

Upgrade procedure

1. Connect your PC to WiDAC (using the USB cable provided)
2. In your pc's web browser enter the following address: <http://192.168.222.254> to bring up the WiDAC's web interface
3. From the list select Firmware Upgrade
4. Browse your PC for the upgrade file and select it
5. Press Firmware upgrade
6. There will be a prompt asking you to confirm the upgrade. Please confirm.
7. The upgrade will take about 3min. You will see the relevant progress bar while the Wi-Fi led on your WiDAC will be blinking.
8. When the progress bar reaches 100%, wait for another 30secs and then unplug the USB cable (ignore the message saying not to cut the power)
9. Place your WiDAC back where you had it and enjoy the improvements of the upgrade!